









Analog output

Differential		Single-ended																																									
<table border="1"> <tr><td>1</td><td>+5V</td></tr> <tr><td>2</td><td>NC</td></tr> <tr><td>3</td><td>OUT+</td></tr> <tr><td>4</td><td>NC</td></tr> <tr><td>5</td><td>OUT-</td></tr> <tr><td>6</td><td>GND</td></tr> <tr><td>7</td><td>KEY</td></tr> <tr><td>8</td><td>GND</td></tr> <tr><td>9</td><td>TS</td></tr> <tr><td>10</td><td>NC</td></tr> </table>  <p>PLD-10</p>	1	+5V	2	NC	3	OUT+	4	NC	5	OUT-	6	GND	7	KEY	8	GND	9	TS	10	NC	<p>VG910H VG910H1 VG910H125C</p>	<table border="1"> <tr><td>1</td><td>+5V</td></tr> <tr><td>2</td><td>NC</td></tr> <tr><td>3</td><td>OUT</td></tr> <tr><td>4</td><td>NC</td></tr> <tr><td>5</td><td>AGND</td></tr> <tr><td>6</td><td>GND</td></tr> <tr><td>7</td><td>KEY</td></tr> <tr><td>8</td><td>GND</td></tr> <tr><td>9</td><td>TS</td></tr> <tr><td>10</td><td>NC</td></tr> </table>  <p>PLD-10</p>	1	+5V	2	NC	3	OUT	4	NC	5	AGND	6	GND	7	KEY	8	GND	9	TS	10	NC	<p>VG035P VG910F VG910F1 VG910F-LN</p>
1	+5V																																										
2	NC																																										
3	OUT+																																										
4	NC																																										
5	OUT-																																										
6	GND																																										
7	KEY																																										
8	GND																																										
9	TS																																										
10	NC																																										
1	+5V																																										
2	NC																																										
3	OUT																																										
4	NC																																										
5	AGND																																										
6	GND																																										
7	KEY																																										
8	GND																																										
9	TS																																										
10	NC																																										
<table border="1"> <tr><td>1</td><td>TS</td></tr> <tr><td>2</td><td>+5V</td></tr> <tr><td>3</td><td>OUT-</td></tr> <tr><td>4</td><td>OUT+</td></tr> <tr><td>5</td><td>GND</td></tr> </table>  <p>PLS2-5S</p>	1	TS	2	+5V	3	OUT-	4	OUT+	5	GND	<p>VG071PT VG103PT VG103E VG103LN VG103S VG103SE VG103S-2LN VG1703S VG1703SPE</p>	<table border="1"> <tr><td>1</td><td>TS</td></tr> <tr><td>2</td><td>+5V</td></tr> <tr><td>3</td><td>AGND</td></tr> <tr><td>4</td><td>OUT</td></tr> <tr><td>5</td><td>GND</td></tr> </table>  <p>PLS2-5S</p>	1	TS	2	+5V	3	AGND	4	OUT	5	GND	<p>VG095M VG103F1 VG103F1-LN</p>																				
1	TS																																										
2	+5V																																										
3	OUT-																																										
4	OUT+																																										
5	GND																																										
1	TS																																										
2	+5V																																										
3	AGND																																										
4	OUT																																										
5	GND																																										
<table border="1"> <tr><td>1</td><td>TS</td></tr> <tr><td>2</td><td>+5V</td></tr> <tr><td>3</td><td>OUT-</td></tr> <tr><td>4</td><td>OUT+</td></tr> <tr><td>5</td><td>GND</td></tr> </table> 	1	TS	2	+5V	3	OUT-	4	OUT+	5	GND	<p>VG091A VG091A-4LN VG191A VG1703 VG1703-2LN</p>																																
1	TS																																										
2	+5V																																										
3	OUT-																																										
4	OUT+																																										
5	GND																																										

Digital output

<table border="1"> <tr><td>1</td><td>RS232 TXD / RS422 TA</td></tr> <tr><td>2</td><td>+5V</td></tr> <tr><td>3</td><td>NC / RS422 TB</td></tr> <tr><td>4</td><td>D_GND</td></tr> <tr><td>5</td><td>GND</td></tr> </table>  <p>PLS2-5S</p>	1	RS232 TXD / RS422 TA	2	+5V	3	NC / RS422 TB	4	D_GND	5	GND	<p>VG095D VG103D VG103LND</p>	<table border="1"> <tr><td>1</td><td>RS422 TA</td></tr> <tr><td>2</td><td>+5V</td></tr> <tr><td>3</td><td>RS422 TB</td></tr> <tr><td>4</td><td>D_GND</td></tr> <tr><td>5</td><td>GND</td></tr> </table>	1	RS422 TA	2	+5V	3	RS422 TB	4	D_GND	5	GND	<p>VG103SD VG103S-2LND VG103S-4LND</p>						
1	RS232 TXD / RS422 TA																												
2	+5V																												
3	NC / RS422 TB																												
4	D_GND																												
5	GND																												
1	RS422 TA																												
2	+5V																												
3	RS422 TB																												
4	D_GND																												
5	GND																												
<table border="1"> <tr><td>1</td><td>+5V</td></tr> <tr><td>2-6</td><td>NC</td></tr> <tr><td>7</td><td>KEY</td></tr> <tr><td>8</td><td>GND</td></tr> <tr><td>9</td><td>RS232 TXD</td></tr> <tr><td>10</td><td>D_GND</td></tr> </table>  <p>PLD-10</p>	1	+5V	2-6	NC	7	KEY	8	GND	9	RS232 TXD	10	D_GND	<p>VG035PD VG910D</p>	<table border="1"> <tr><td>1</td><td>+5V</td></tr> <tr><td>2-5</td><td>NC</td></tr> <tr><td>6</td><td>GND</td></tr> <tr><td>7</td><td>KEY</td></tr> <tr><td>8</td><td>GND</td></tr> <tr><td>9</td><td>RS422 TA</td></tr> <tr><td>10</td><td>RS422 TB</td></tr> </table>  <p>PLD-10</p>	1	+5V	2-5	NC	6	GND	7	KEY	8	GND	9	RS422 TA	10	RS422 TB	<p>VG035LND VG910D1</p>
1	+5V																												
2-6	NC																												
7	KEY																												
8	GND																												
9	RS232 TXD																												
10	D_GND																												
1	+5V																												
2-5	NC																												
6	GND																												
7	KEY																												
8	GND																												
9	RS422 TA																												
10	RS422 TB																												
<table border="1"> <tr><td>1</td><td>RS422 TA</td></tr> <tr><td>2</td><td>+5V</td></tr> <tr><td>3</td><td>RS422 TB</td></tr> <tr><td>4</td><td>D_GND</td></tr> <tr><td>5</td><td>GND</td></tr> <tr><td></td><td>B (for factory use)</td></tr> <tr><td></td><td>A (for factory use)</td></tr> </table>	1	RS422 TA	2	+5V	3	RS422 TB	4	D_GND	5	GND		B (for factory use)		A (for factory use)	<p>VG191AD</p>														
1	RS422 TA																												
2	+5V																												
3	RS422 TB																												
4	D_GND																												
5	GND																												
	B (for factory use)																												
	A (for factory use)																												